


SEAFARER C-SHAPED PARTY TABLE



FOR CUSTOMER SERVICE, PLEASE WRITE OR CALL:

FOREMOST INTERNATIONAL
906 MURRAY ROAD
EAST HANOVER, NJ 07936
















TEL: 1-800-443-1410

FAX: 1-973-428-6166

EMAIL: customerservice@foremostgroups.com

Visit our web site at www.fitnjo.com

BEFORE YOU START: READ THE INSTRUCTIONS THOROUGHLY PRIOR TO ASSEMBLING. CHECK ALL COMPONENTS AND PARTS AGAINST THE PARTS LIST TO ENSURE A SAFE AND PROPER ASSEMBLY.

NO.	PARTS LIST		QTY	NO.	PARTS LIST		QTY
A	TABLE TOP		1	I	WRENCH		1
B	C-SHAPED MESH SHELF		2	J	APRON BAR		2
C	L-SHAPED LEGS		3	K	FOOTREST BAR		1
D	S-SHAPED LEGS		5	L	APRON		1
E	LONG BOLT		15	M	NUT		15
F	SHORT BOLT		32	N	NUT COVER		15
G	WASHER		15	O	BOLT COVER		15
H	HEX SCREW DRIVER		1	P	BOTTLE OF TOUCH-UP PAINT		1


ASSEMBLY INSTRUCTION

* SELECT AN AREA WITH A SOFT NON-ABRASIVE SURFACE SUCH AS CARPET TO PROTECT THE COMPONENTS DURING ASSEMBLY.

* CAREFULLY REMOVE ALL THE COMPONENTS FROM THE CARTON.


* PLACE THE TABLE TOP (A) UPSIDE DOWN ON THE ASSEMBLY AREA AND START THE ASSEMBLY.

1. INSERT 3 L-SHAPED LEGS (C) INTO THE LEG BRACKETS ATTACHED TO THE INSIDE TABLE RIM.




STEP 1

2. INSERT 5 S-SHAPED LEGS (D) INTO THE LEG BRACKETS ATTACHED TO THE OUTSIDE TABLE RIM.




STEP 2

3. PLACE THE TOP C-SHAPED MESH SHELF (B) BETWEEN THE LEGS AND ATTACH THE LEGS TO THE C-SHAPED MESH SHELF LOOSELY USING THE SHORT BOLTS (F), AND REPEAT THE SAME PROCEDURE FOR THE BOTTOM C-SHAPED MESH SHELF. ONCE ALL THE LEGS ARE ATTACHED TO THE C-SHAPED MESH SHELF, USE HEX DRIVER TO TIGHTEN THE SHORT BOLTS (F).



STEP 3

4. ATTACH THE FOOTREST BAR (K) TO EACH S-SHAPED LEG WITH LONG BOLT (E), WASHER (G) AND NUT (M) BY USING WRENCH (I) AND HEX SCREW DRIVER (H).



STEP 4

5. ATTACH THE TOP APRON BAR (J) TO EACH S-SHAPED LEG WITH LONG BOLT (E), WASHER (G) AND NUT (M) BY USING WRENCH AND HEX SCREW DRIVER.



STEP 5

6. SLIDE BOTTOM APRON BAR (J) TO APRON (L) (SIDE WITHOUT VELCRO).



STEP 6

7. ATTACH THE BOTTOM APRON BAR WITH APRON TO EACH S-SHAPED LEG WITH LONG BOLT (E), WASHER (G) AND NUT (M) BY USING OPEN WRENCH AND HEX SCREW DRIVER.



STEP 7

8. ATTACH TOP ENDS OF APRON TO THE TOP APRON BAR BY FOLDING VELCRO ENDS AROUND THE APRON BAR. THEN ATTACH SIDE ENDS OF APRON TO THE OUTSIDE L-SHAPED LEGS BY FOLDING VELCRO ENDS AROUND THE LEGS. MAKE SURE TO LEVEL OFF THE SURFACE OF FABRIC BY PRESSING HARD.




STEP 8

9. COVER ALL BOLTS WITH BOLTS COVERS (O) AND NUT COVERS (N) RESPECTIVELY.



STEP 9

10. WITH THE HELP OF ANOTHER PERSON, TURN TABLE UPRIGHT.



STEP 10

11. NOW YOUR PARTY TABLE IS READY FOR USE.

* KEEP THE TOUCH UP PAINT BOTTLE (P) FOR FUTURE USE FOR BOTH YOUR TABLE AND CHAIRS.

NOTE:

Repeated assembly can weaken the locking ability of the washers. Periodically check all bolted connections on your furniture to make sure they are tight and secure. Retain these instructions for future reference.

CAUTION:

If you are using an umbrella with the table, make sure that the plastic ring is inserted into the hole in the center of the table and insert the umbrella through the opening. Use a cast iron or steel plate base or a plastic blow molded umbrella base that can hold a minimum of 50 lbs. Do not insert the umbrella into the table without using a base. Be sure close the umbrella when not in use and do not leave the umbrella in the open position during windy conditions.